

1. Receiver
2. Barrel
3. Slide
4. Plunger Tube
5. Slide Stop Plunger
6. Plunger Spring
7. Safety Lock Plunger
8. Slide Stop
9. Rear Sight
10. Front Sight
11. Barrel Link
12. Barrel Link Pin
13. Barrel Bushing

14. Recoil Spring
15. Recoil Spring Guide
16. Recoil Spring Plug
17. Extractor
18. Ejector
19. Ejector Pin
20. Firing Pin
21. Firing Pin Spring
22. Firing Pin Stop
23. Hammer
24. Hammer Pin
25. Hammer Strut
26. Hammer Strut Pin

27. Main Spring
28. Main Spring Cap
29. Main Spring Cap Pin
30. Sear
31. Sear Spring Assembly
32. Sear Pin
33. Disconnecter
34. Trigger Assembly
35. Grip Safety
36. Safety Lock
37. Main Spring Housing
38. Main Spring Housing Pin
39. Main Spring Pin Retainer

40. Lanyard Loop
41. Lanyard Loop Pin
42. Magazine
48. Magazine Catch
49. Magazine Catch Spring
50. Magazine Catch Lock
- 51L. Left Grip
- 51R. Right Grip
52. Grip Screw
53. Frame Bushing
54. Grip Screw Escushion

